

TRUE BLUE™ BALL VALVES

INSTALLATION INSTRUCTIONS

INSTALLATION AND MAINTENANCE

FLOW DIRECTION: Due to the Trunnion design these valves are capable of handling flow and pressure in either direction.

THREADED CONNECTIONS: Use Teflon® tape or a suitable pipe sealant on threaded connections. Use a strap wrench to tighten only 1/4 turn more than hand tight. Do not use metal pipe wrenches.

SOCKET CONNECTIONS: (PVC and CPVC only). Cut pipe ends square and deburr. Clean mating surfaces with proper solvent. Apply cement to surfaces and immediately assemble with 1/2 turn rotating motion. Caution: Do this disassembled from valve to avoid damage. For Polypropylene Thermal Socket Fusion, follow fusion equipment manufacturers' recommendations. For more information contact your Plast-O-Matic distributor.

ADJUSTMENTS: If valve is leaking at the Teflon® seats or end o-rings simply tighten the union nuts with the valve in closed position. If leaking continues then replacement of faulty part is necessary. If leaking occurs at the stem o-ring then replacement is necessary. Only hand tighten union nuts. Do not use wrenches.

DISASSEMBLY OF DOWNSTREAM PIPING: The Trunnion design of this valve enables you to disassemble the downstream piping from the valve by unscrewing the valve's downstream union without leakage from the upstream pressure. To do this, first close the valve, then slightly loosen the downstream union, then tighten the upstream union, and then completely remove the downstream union. Use extreme caution with dangerous fluids.

VALVE REMOVAL FROM PIPING: The True Union design enables you to simply unscrew the two valve union nuts and slide the valve body away from the piping. Pressure or liquid head must be removed from both sides of valve before doing this. Use extreme caution with dangerous fluids.

Teflon is a registered trademark of DuPont.

PLAST--MATIC
VALVES, INC.