


PUMP SERVICE BOOK




TC-X030V TC-X050A TC-X050S
TC-X050P TC-X050P-PP TC-X050V TC-X050D

Series Pumps







 **IWAKI**

1-① AT ST







1





1-② PT VT DT PT-PP



2-① AT ST




2-② PT VT DT



3




3-①




AT
ST









3-②

PT
VT
DT









6

6-2

